



Battery 36V

Air Switch

Fuse 10A  
Charger Socket

Ignition:+36VDC  
Fuse 5A

Phase W  
Hall Sensor  
Phase U  
Phase V  
Motor

ACC for Controller

+5V  
Throttle  
GND  
Throttle

Controller  
Signal

Brake Signal

GND

Speed Signal

Speed Meter

Front and Rear  
Brake Switch

Horn Switch

Rear Position Light  
Brake Light  
Rear Light Set

Front Head Light

Horn